

# ROOM S (MEETING ROOM, OPEN MEETING ROOM, FOCUS ROOM) SPRINKLER INSTALLATION DIAGRAM REVC

## TOOLS NEEDED:

- 1) BLUE TAPE
- 2) 2.5" HOLE SAW
- 3) POWER DRILL

## INSTRUCTIONS:

- STEP 1: GENEROUSLY COVER CEILING AND ROOF VENEER/LAMINATE WITH BLUE TAPE AROUND HOLE LOCATION.
- STEP 2: USING A 2.5" HOLE SAW, DRILL FROM ABOVE (ROOF SIDE) AT THE MARKED LOCATION UNTIL THE CENTER DRILL BIT PASSES THROUGH THE LOWER PLYWOOD.
- STEP 3: COMPLETE THE 2.5" HOLE FROM BELOW (CEILING SIDE) USING THE CENTER HOLE AS A GUIDE.
- STEP 4: REMOVE ALL BLUE TAPE AND INSTALL THE SPRINKLER PER THE MANUFACTURER'S INSTRUCTIONS.

